
Anchoring of the SAFE

- S1 Series : According to European standard EN 14450 all safes under 1000kg must be equipped with two floor anchors; otherwise burglary classification (S1) is not valid.
- S2 Series : According to European standard EN 14450 all safes under 1000kg must be equipped with two floor anchors; otherwise burglary classification (S2) is not valid.
- Grade1 Series : According to European standard EN 1143-1 all safes under 1000kg must be equipped with one floor anchor; otherwise burglary classification (Grade1) is not valid.

Floor anchoring bolts should be fixed into concrete floor (corresponding anchoring equipment can be used for other floor materials). User of the safe is responsible for the proper anchoring of the safe.

- Install the safe in a place where you can drill 1 or 2 holes
- Check that the drilling spots are safe. Drill 55 mm deep holes into the floor through the bottom holes of the safe. Use an effective impact drilling machine with 15 mm diameter bit
- Use e.g. vacuum cleaner to clean the holes
- Fix the anchors into the holes without bolts. Hit the anchors as deep as possible by hammer and diam. 8-10mm bar
- Screw the bolts as tight as possible
- If the safe is Media safe, fix the plastic cover plugs back.
- If the standard anchoring material not suitable for your ground (e.g. wooden floor), you can use also an equivalent anchoring material suitable for your ground. Diameter, strength class and dimension of the washer must be the same as the supplied anchoring material. In case of any question please consult your dealer or the insurer.